

Instructions for changing Probe interface chips on MSR1-1

In some cases there is a spare probe interface chip on the MSR1-1 controller card. **Make sure that the power supply to the board has been turned off before removing or inserting any components.**

A small screwdriver tip can be used to lift the chips from the controller board, but care should be taken that the legs are kept straight, and that the parts are replaced the same way around as they were originally (the small notch in the chip should be at the same end as the notch in the chip-holder on the controller board). Care should also be taken that the legs of the chip are inserted into the metal slots of the socket and that it sits securely.

